## **INSTRUCTIONS**

## **SERVICE & MAINTENANCE KIT**

# #3G58900--#3G58891--#3G58892

#### **#1G54040 LID FILTER:**

- A.) Unlatch the powder recovery lid from your hopper and place the lid on a flat surface with the old lid filter facing toward you.
- B.) Lift at one corner of the lid filter and carefully pull away for the powder recovery lid.
- C.) Place the new lid filter on pulling down around each corner till the filter is on all the way on.
- D.) Reinstall lid onto hopper and latch to secure.

## **#1G0067 JAR FILTER & #1G0205 JAR GASKET:**

- A.) Remove the plastic recovery jar from the bottom of the control console, jar filter retaining cap ad old jar filter.
- B.) Remove the jar gasket from the jar holder, clean the jar and filer holders with a damp cloth.
- C.) Reinstall the jar gasket, jar filter, filter retaining cap, and plastic recovery jar to the control console.

### **#3G0151 VENTURI:**

- A.) Follow the "clear" color vent line up inside the control console unit it connects to a brass tee. "This is the venturi"
- B.) Remove the  $\frac{1}{4}$ " brass nuts and plastic lines from the brass tee (venturi) and unscrew the brass tee (venturi) out of the vent line.
- C.) Remove the ¼" brass nuts from the new venturi and insert the port of the venturi with the plastic tube on it into the "clear" vent line.
- D.) Realign the venturi to match the plastic lines and carefully tighten the  $\frac{1}{2}$ " brass nuts.

### **#1G52172 YEARLY MAINTENANCE STICKER:**

- A.) Clean the front of the hopper with a damp cloth and wipe dry.
- B.) Place yearly maintenance sticker on the upper left corner of the hopper just below the latches.

The rest of the parts included in this kit may be used for any component in the system that may need to be replaced.

### "OTHER ITEMS THAT MAY NEED SERVICE":

- A.) Lube the on-off control valve with a light coat of Vaseline or o'ring lube.
- B.) Wipe down the inside of the hopper to remove any hardened chemical.
- C.) Check all plastic lines for cracks or kinks. Replace if necessary.
- D.) Blow out the inside of the control console to remove chemical residue.
- E.) Clean the vent line of chemical residue that would restrict air flow.

REFER TO THE OWNERS MANUAL FOR OTHER PARTS OR SERVICE NEEDED