



Instructions for Use



smokecenturion can be used either hand-held or with the **Solo 330** dispenser, offering ultimate flexibility and convenience on-site.

Hand-held use

- Shake canister well before use
 - Holding upright, spray at detector from no closer than 12 and no further than 40 inches
- *SILICONE FREE TESTING**
- Spray for 0.5 – 1 second repeating every 10 seconds for no more than 1 minute until detector is activated
 - If detector fails to respond it may be faulty

Dispenser use

- Shake well before use
- Insert can into Solo smoke dispenser, lock into place using screw mechanism and place dispenser cup over detector
- Discharge spray by pressing upward
- Spray for 0.5 – 1 second repeating every 10 seconds (holding cup in place) for no more than 1 minute until detector is activated
- If detector fails to respond it may be faulty



Use only in accordance with directions.

No liability can be accepted for incorrect use.

[Instructions d'utilisation](#)